

S
H
U
T
T
E
R
K
I
T
S


140 x 24 Top & Bottom Rail
(140 is Variable)

Rotation Bar


60 x 30 Stile




68 x 10 Flat Blade




84 x 10 Flat Blade



68 x 14 Elliptical Blade



90 x 15 Elliptical Blade



140 x 24 Top & Bottom Rail
(140 is Variable)

Front of Shutter

